

Colorcraft.us installation instructions for tub Wall Mount Tub Filler

480094

Have your faucet installed by a licensed plumber.

Turn your water off using your stops on the supply lines if you have them, or turn off the water to your building.

This faucet has 3/4 IPS inlets. The inlets will connect to your supply lines, this faucet comes with the nuts to fit right on your . If you are using flexible supply lines you will need a Pair of Clawfoot Faucet Ells (400676, Not found at your local hardware store.)



To install the faucet you will need to remove the nuts that are on the inlets then slide the inlets through the holes on your tub. Take note as to how they are facing, you will want to put them back on the same way.

This is a wall mount faucet which means it will mount to the inside of your tub, the part of your tub that is parallel to your wall and on the inside.



This faucet has 3 3/8th holes which are not adjustable, the holes for mounting your faucet are 3 3/8 in across from the center of one to the center of the other. Slide your Inlets inside the holes on your tub, keeping the down spout facing down, and the attachment side facing up.

The nuts you removed earlier will hold the faucet in place once you screw them back on. Put the wider rounder side towards the tub to give it a nice hold. (Not too tight, don't crack the tub!)



Inside the box for the faucet you will find the handles, the body of the faucet, and the spout. To find the spout you will need to remove the faucet and handles then remove the Styrofoam and turn it over. Your spout will be attached to the other side.

Attach the spout to the body of the faucet using teflon tape

Your hand held attachment includes the spout which will look like an old telephone receiver this attaches to the hose and will connect right on with teflon tape.



To attach the holder you will remove the nut from the top of the faucet and screw it right on with teflon tape. (Keep the nut incase you want to switch to a riser for a shower later on in life)

You can then attach the hose to the holder using teflon tape. You will attach the hand held to the hose using teflon tape and, Now simply set the handheld in the cradle.



This end of the hose goes to the Holder.



The handles for this faucet are labeled. Hot goes on your left as you are looking at it and cold on your right. The diverter handle is in the middle, and says "shower".

remove this



To attach the handles you must remove the screws at the end of the stems (where the handle will attach).



use screw to hold in place



Simply slide the handles onto the stem use the handle as a lever and tighten them down make sure they are in the correct position (don't use too much force you will break it) reposition your handle and replace the screw to hold the handle in place. . (Once you hook up your water you may adjust the handles to your liking.)

When you turn on your water make sure someone is holding the hand held facing into the tub, IF your diverter is open for the handheld it is likely to pop out of the holder and chip.

You are now ready to connect your supply lines (directions can be found under supply line directions).



Colorcraft.us